




## DIGITAL LEATHER THICKNESS GAUGES

DATA  
OUTPUT



2262-10

- Measure thickness of leather
- Buttons: on/off, inch/mm, zero, data preset, change measuring direction, absolute/incremental measurement
- Keep preset data in memory after restart
- Battery CR2032, automatic power off (time is adjustable)
- Data output
- Optional accessory:  
wireless transmitter code **7315-50M** (receiver is needed)



| Code     | Range         | Resolution     | Accuracy | Type |
|----------|---------------|----------------|----------|------|
| 2262-10  | 0-10mm/0-0.4" | 0.01mm/0.0005" | ±0.02mm  | A    |
| 2262-10B | 0-10mm/0-0.4" | 0.01mm/0.0005" | ±0.02mm  | B    |