



DIGITAL INTERNAL THREAD TAPER MEASURING INSTRUMENT

principle of measurement

step 1:



step 2:




taper calculation formula: $\text{taper} = A/H$
A is the reading difference of two measurements
H is the distance between two measuring positions



2241-6

- Measure the taper of internal thread
- Digital indicator stroke: 25.4mm/1"
- Optional accessory:
wireless transmitter code **7315-50M** (receiver is needed),
ball points (code **6252** series)

Unit: mm



Code	Range (L)	Travel of measuring tip	Resolution	Any 6mm accuracy
2241-6	1.5-6"/38.1-152.4mm	1"/25.4mm	0.0005"/0.01mm	0.04mm